

+ InSpec® N7
Low Toxicology, pH Neutral
Detergent Solution.



+ ORDERING INFORMATION

InSpec® N7 Products

Product	Pack Size	Case Size	Redditch Code	AMD Code
InSpec® N7 1L Trigger Spray	1L Trigger Spray	6 x 1L	N7WF1CC-1LS	D06C10D
InSpec® N7 5L Screw Cap	5L Screw Cap	2 x 5L	N7WF1-5LS	D02C00D
InSpec® N7 Concentrate	100ml Screw Cap	50 x 100ml	N7WF1-100MLS	D50C01D
InSpec® N7 Session Pouch 15 pc	15 Wipes	25 per case	N7WFIPCH15S	W25C15D

Please use the AMD Code when ordering.

AMD are the official UK distributor for Redditch Medical's range of products to the NHS, pharmacies and compounders.

+ PRODUCT INFORMATION

Use Instructions

InSpec® N7 is designed for cleaning hard surfaces by spraying, wiping and mopping. Hold spray approximately 15cm to 20cm from the surface area. 5L versions, pour into an appropriate container for mopping. 100ml concentrate added to 2.4L of water is required for mopping. Apply to surface to ensure complete coverage.

Technical Data

InSpec® N7 Ready to Use (RTU) is a 4% neutral detergent, pH 6.0 - 7.0. The neutral detergent has surfactant and sequestering agents designed to assist the removal of process residue and light soiling in a cleanroom environment.

Storage

Store upright in original closed containers, away from sunlight and extremes of temperature. Full guidance on the handling and disposal of this product is available in the Safety Data Sheet (SDS).

Safe Handling

Always wear gloves and goggles or face protection. Always read the label and SDS before use.

Material Compatibility

Application of solutions, when used as directed, will not affect materials normally encountered. Compatibility information in the Technical File.

Benefits

- Designed for cleaning floors, walls, ceiling and other hard surfaces for the removal of process derived residue and light soiling.
- Ideal for critical surfaces with soiling near to product manufacturing
- Very low foaming, low residue detergent with an excellent low toxicology profile
- Suitable for manual cleaning and available in convenient ready to use and concentrate formats.
- Low concentration
- All formats manufactured with WFI quality water
- Multiple bags for cleanroom transfer
- Manufactured to GMP

Technical User Information

InSpec® N7 is available in sterile RTU pre-diluted formats and as a concentrate.

InSpec® N7 is manufactured to GMP and is filled and capped in an ISO class 5 environment.

RTU solutions are diluted with WFI quality water.

The solution is filtered through a 0.2 micron filter and gamma irradiated (20 - 50 kGy for 5L products) to a validated process to give a sterility assurance level SAL of 10⁻⁶.

For screw cap bottles use the entire contents after opening.

Aseptic Medical Devices

Newmarket Drive, Derby DE24 8SW | +44 (0) 1332 755622
sales@asepticmedical.com | www.asepticmedical.com

Aseptic Medical Devices is a trading name of Riverside Medical Packaging Company Limited